

Adjusting the Touchscreen...

Your touchscreen now has **HEIGHT** and **TILT** adjustment.

This is for your comfort, so that:

- the screen will move with you when you move between sitting or standing;
- you can set the screen at the right height for you to work with.



It is important that you know how to adjust the touchscreen so that the workstation is comfortable and right for you. The screen should be placed so that you can:

- see it comfortably with no glare or reflection from store lighting;
- reach it easily and without having to move your shoulder upwards.

The screen moves in two ways – height and tilt – so you need to adjust it in two different movements.

Take hold of the screen by diagonal corners, shown by the red arrows in the picture.

Move the screen up or down to where you want it to be for use.

Once the screen is in the right height position, then adjust the tilt so you are looking at it perpendicularly, and it is 'facing' you.